Bennett W. Manning



REAL-TIME SYSTEM

# REFERENCE CARD-II

(SOFTWARE)

# SPECIAL SYMBOLS

SYMBOL	80-COLUMN PUNCH	USE  In column 1: indicates primary control statement In any other column: indicates continuation of control statement to next card				
#	12-7-8					
Δ	11-7-8	Separates notes from statement on primary control card Indicates termination of parameters on PRAM control card				
, 0-3-8 (comma)		Separates specification fields: two commas (,,) in succession required to indicate blank specification (except last)				
b (blank)	(none)	In column 1, followed by mnemonic operator: indicates secondary control statement and delimits its operator In primary control statement: delimits options field; two blanks (BB) in succession required for blank option field followed by specifications Indicates termination of statement				
/ 0-1 Separates subfields within a specification		Separates subfields within a specification				

date: year and month yyddd

PRIMARY CONTROL #GOboptionsbname/version,library (E) options: A-E = logical test switches ACTIVATI R = clear switches H, M, or L = service and selection priority (high, medium, or low) X or Y P = 90-column FORTRAN input cards CORE EXTEN #CORPHOminimum /maximum minimum: minimum extension (no. of words) of core required for task element maximum: maximum extension desired #ASGboptionsbperiphral code, file code, minimum/maximum options: J = hold for job duration or until # FREE no J = hold for task termination RANDOM ACCESS V = assignment optional for task execution peripheral code: DRUM = FH-432 drum, FH-1782 drum or FH-880 drum F432 = FH-432 drum only F1782 = FH-1782 drum only F880 = FH-880 drum only
FAST = normal track on FASTRAND drum FBAN = Fastband track on FASTRAND drum RAN = FH-432 drum, FH-1782 drum, FH-880 drum, or Fastband or normal track on FASTRAND drum SEQ = FH-432 drum, FH-1782 drum, FH-880 drum, Fastband or normal track on FASTRAND drum, or magnetic tape unit minimum/maximum: no. of assigned words #ASGboptionsbperipheral code, file code, file name 1 options: H = 800 fpi M = 556 fpi L = 200 fpi no H, M, L = 556 fpi F = fixed or compatible mode (UNISERVO II A) E = even parity recording MAGNETIC TAP no E = add parity U = inhibit automatic block numbering N = inhibit noise record constant R = rewind without interblock after mounting V = assignment optional for execution T = translate BCD to Fieldata (FD) on read, FD to BCD on write (requires E option) W = wait for operator response peripheral code: TAPE = any available tape unit UN3C = UNISERVO III C only UN6C = UNISERVO VI C only (7-track mode) UN&C = UNISERVO VIII C only (7-track mode) UN2A = UNISERVO II A only UN3A = UNISERVO III A only COMP = UNISERVO VI C or VIII C with 9-track option #ASGBoptionsBperipheral code, file code options: B = column binary T = XS-3 or 90-column code to FD on read, FD to XS-3 or 90-column code on punch no B and T = translate card image V = assignment optional peripheral code: CIN8 = 80-column card reader except primary input COUT8 = 80-column punch except secondary output CIN9 = 90-column card reader except primary input COUT9 = 90-column punch except secondary output 1 #ASGboptionsbperipheral code, file code, um/bm/pl options: V = optional assignment J = hold until #FREE or end of job no J = release at termination of task peripheral code: PRINT = high speed printer or UNIVAC 1004 subsystem except primary output um: no. of lines for upper margin bm: bottom margin pl: text lines or (for user form control) 0 (zero) no um/bm/pl: use system parameters #ASGboptionsbperipheral code,file code options: J= hold until #FREE or end of job no J = hold to task termination V = optional assignment peripheral code: PTIN = paper tape reader PTOUT = paper tape punch 1 #LASGboptionsbvo,file code,v2,priority,v4,v5 options: A = register additional handler queue process activity addendum H = load, link remote line handler O = optional CTM D = wait for CTM M = assign only CTM updated for maintenance testing X = level 1, disregard file code and own code vo: peripheral code, naming CTM type or block assigned remote line handler name/version priority: octal 0-17

 $v_4$ : (optional) name/version of output own code (user task to staging)

(optional) name/version of output own code (random access to remote handler)

CONTRO

STEM

PRIMARY CONTROL #OUTboptionsbv0,v1,v2,v2... options: X, Y, Z, or no X, Y, and Z C = specified elements submitted to secondary job output F = write EOF tape mark after last element L = only RB elements in output M = only load elements in output N = only source elements in output R = initial rewind of output tape S = system or group library format will be generated by inclusion of elements from given library vo: (only if no C option) file code of device to receive elements v1: output library/(if S option) group library file no. assigned to output elements v2,v2...: name/version of elements to be transferred from library; no v2,... = all elements from specified library will be transferred to specified device (v0) #PRTtoptionstilibrary ,v,v,... (E) options: X, Y, Z, or no X, Y, and Z T = print only TOC name/version of element(s) to be printed; no v's,...= all elements of specified library will be printed #REPORTToptions (E) options: P = abort task at completion of initialization if parameter error F = abort task if file error no P and F = continue to end of input or fatal error #REXtoptionstcore requirements E (5) options: X or Y no X and Y = abort task on fatal error core requirements: minimum required/maximum desired in no. of words. Maximum limited to 32K minus 400<sub>8</sub> #SPURTtoptionstname/version (E) options: X, Y, Z, or no X, Y, and Z D = delete card columns 1-6 from side-by-side listing E = assign all extra core to table expansion L = list program labels and control counter values with source and object code N = list diagnostics only S = list SDEF's with RB element R = list labels and references, alphabetically sorted P = list XREF's and references A = sort labels alphabetically (with S or L option) #TESTboptions,name/version,library (5) (E) options: A-E = logical test switches R = initial clear of switches #UTLtoptionstname/version (S) (E) options: X, Y, Z, or no X, Y, and Z NOTES: = can be used internally; = requires # END card; = secondary language associated SECONDARY CONTROL **BENTRY**bbname name: EDEF of element to be collected tequalSttname/value,name/value,... value: octal or decimal value assigned to XREF

bEXCLUDEbbname/version,name/version,... name/version: RB element from library to be excluded from collection tINCLUDEttname/version,name/version,... name/version: RB element from library to be included in collection tMAPtbname/version,name/version,... name/version: MAP element to be collected tSEGMENTbbsegment name 1, segment name 2 tSEGMENTbbsegment name 1,(segment name 2,segment name 3,...) segment name 1: name of segment segment name 2: no parentheses = segment name 1 and segment name 2 originate at same location with parentheses = segment name 1 starts immediately after highest location of segment names in parentheses no segment name 2 = segment name 1 has origin immediately after the preceding

segment bATbbp/switch 1,set count/iteration count,switch 2

p: location of instruction to be executed

switch 1: (optional) execution — enabling switch for nested procedures set count: counter value required to set switch 2

iteration count: maximum no. of times switch 2 can be turned on; if not specified, no limit

switch 2: switch A-Z, turned on when counter reaches p

tDUMPtoptionstP/switch,v0,v1,v2,v3

options: O = octal representation

A = Fieldata

D = decimal

F = decimal representation of double precision floating point

C = start printout on new page

L = list task control thread

P = specifications refer to peripheral device P/switch : program location/conditioning switch

vo: file code; if not specified = core is requested

v1: no. of blocks (tape) or no. of words to be skipped v2: start address (no tag or label) - logical address (random access), or no. of blocks

(tape ) or beginning address (core)

no. of lines between print images; if not specified = 1

v3: (optional) relative address twRITEOFtoptionstfile code options: see note

NOTE: General options for #UTL secondary control D = follow data file conventions R = do not update logical increment for this file F = perform jump if false (test operator only)

A = translate element as action operator (used for special user own code)

#### GENERAL SERVICE REQUESTS SENERAL SERVICE REQUESTS **TCORES** ABORTS (A) = LL of requesting activity and size of task code (0) = RIRCARORTS (B7) = total size of contiguous task core TESTFL\$ CEXIT\$ (A) = 1 indicates floating point overflow CHECKPOINTS (A) = -1, FP underflow (A) = 0, no FP overflow or underflow CLEARDS **TESTOFS** CMOVEStdata area address, size of data area (A) = 1, FP overflow (A) = 0, no FP overflow CSWCTSbservice call of another subroutine **TESTUFS** CVT\$baddress,size (A) = 1, FP underflow address: relative to LL (A) = 0, no FP underflow size: no. of words in field DELAY\$binary no, representing milliseconds TCF\$tile code to be tested DATIMS (A) = yyddd in Fieldata (Q) = Fieldata :ssbb (Q) = binary no. of clock updates since midnight ERRADD\$baddress of routine (A) = binary no. of Real Time Clock updates (A) = status word (Q) = max, no. of updates allowed ERROR\$ FADD\$tile code, no. of words (A) = Fieldata yyddd (Q) = binary time of day in quantums FBAD\$tile code, no. of words, logical increment FETCH\$\( b\) base address, name/version, library (A) = Fieldata yyddd(Q) = binary no. of 100-millisecond units since start of year FETCHL\$base address,name/version,library UST\$6v0,v1,v2,v3 FOFADD\$bstart address of recovery routine vn: base address, relative to LL FORK\$bstart address (relative to LL of requesting activity) v1; deposit area base address, relative to LL deposit area size FREL\$bfile code, no. of words, logical increment v3: 0 or length of pickup area FRELAStile code, no. of words, logical increment XOFF\$5switches A thru E in #JOB or #GO statement FUFADD\$\bar{b}\start address of recovery routine XONST switches A thru E in #JOB or #GO statement JOINS XTEST\$bswitches A thru E in #JOB or #GO statement LOAD\$blabel of segment to be loaded $(A)_{29}$ thru $(A)_{25}$ = status of switches A thru E LOADAS' tag (load and activate) MADD\$bno. of words I/O SERVICE REQUESTS MREL\$bno. of words, (optional) routine address BLOCKR\$5v0,v1,v2,v3 QREF\$bbinary identity of queued activity (v3 in REGQ\$) vo: file code RECEIVE\$bv0,v1,v2 v1: no. of words vo: base address relative to LL v2: buffer base v1: max. no. of locations v3: logical increment v2: (optional) identity no. BLOCKS\$to,v1,v2,v3,v4 REG\$to, v1, v2, v3, v4, v5 vo: file code v<sub>0</sub>: relative address of activity v<sub>1</sub>: activity mode indicate no. of words v1: no. of words v2: buffer base v2: (optional) relative response priority 0 thru 178 v3: (optional) starting address of data, relative to LL logical increment v4: search identifier v<sub>4</sub>: size of data area (required if v<sub>3</sub> specified) v<sub>5</sub>: (required if v<sub>3</sub> specified) data area mode indicator CARDStbuffer base CHANGESTV0,V1,V2 $\mathsf{REGQ\$tv}_0, \mathsf{v}_1, \mathsf{v}_2, \mathsf{v}_3$ vo: relative address of requesting activity v1: activity mode indicator label for demounted file v1: label for demount v2: label of new file (optional) relative response priority 0 thru 178 v2: (optional) relative respons v3: binary identity of activity DEMOUNT\$bfile code,file identifier RESTARTS ERASEStile code RETURNS GWRITEStabel of LISTAS RETURN1\$ LIST\$tile code, no. of words, logical increment SEND\$tv0,v1,v2 LISTA\$50,0,01,02,03,04,... vo: data area base, relative to LL vo: file code no, of locations to transfer vj: no. of buffers v2: 15-bit binary identity no. v2: logical increment v3,v4,...: no. of words/base,no. of words/base,... SET155 LISTB\$bv<sub>0</sub>,v<sub>1</sub>,v<sub>2</sub>,v<sub>3</sub>,... SET17\$ vo: file code SETD\$ v1: no. of buffers v2,v3,...: no. of words/base/logical increment,no. of words/base/logical increment,...

MOUNT\$bfile code,file identifier

# I/O SERVICE REQUESTS MREADStabel of LISTBS PRINTSTV0,V1,V2 vo: buffer base address v1: no. of words v2: line spacing before print PUNCH\$tbase address,no. of words READ\$50,01,02,03 vo: file code v1: no. of words buffer base v2: buffer base v3: logical increment (optional for unit record or tape) READB\$tile code, no. of words, buffer base READL\$60,01,02,03 vo: file code vi: no. of words buffer base v2: buffer base v3: logical increment (optional for unit record or tape) REWIND\$tile code SEARCH\$tv0,v1,v2,v3,v4 vo: file code v1: no. of words v2: buffer base v3: logical increment v4: search identifier SEARCHLSTV<sub>0</sub>,v<sub>1</sub>,v<sub>2</sub>,v<sub>3</sub>,v<sub>4</sub> (same format as SEARCH\$) SREADS blabel of LISTAS UNSOL Shlabel WRITE\$ + v0, v1, v2, v3 vo: file code (label of LIST\$) no. of words or (for printer) line spacing before print v2: buffer base v3: logical increment (not used for printer) WRITEOFStile code WRITER\$50,0,0,0,0,03 vo: file code v1: no. of words v2: buffer base v3: logical increment (optional for unit record) REMOTE LINE CONTROL SERVICE REQUESTS CTMFREE\$bline identifier of CTM GETM\$bv0,v1,v2 vo: 15-bit numeric identifier of CTM control block v1: no. of words v2: buffer base GETMW\$5v<sub>0</sub>,v<sub>1</sub>,v<sub>2</sub> (same format as GETM\$) LACQ\$tv\_0,v1,v2 (optional) name/version of input own code (handler to staging) v<sub>1</sub>: (optional) name/version of input own code v<sub>2</sub>: (optional) input own code (staging to user) LDOWN\$ numeric line identifier of CTM and unit no. LOOKM\$Tov0, v1, v2 vo: file code (same as on LACQ\$) no. of words v1: no. of word v2: buffer base LUP\$\understand numeric line identifier of CTM and unit no. PUTM\$bbuffer base,no. of words READMSTV0,V1,V2 vo: file code (same as on LACQ\$) v1: no. of words

v2: buffer base

READMW\$tv<sub>0</sub>,v<sub>1</sub>,v<sub>2</sub> (same format as READM\$)
WRITEM\$tbuffer base,no. of words

## PRIMARY CONTROL STATEMENT FORMAT

# mnemonic b o	ptionoptionoption	D	v <sub>0</sub> ,v <sub>1</sub> ,v <sub>2</sub> ,,v <sub>n</sub>
# operator To	option(s)	to	specification(s)

#### COMMON OPTIONS

(where listed with statement): X = error during loading or execution aborts task and

remainder of job

or assembly

Y = completed task is accepted for execution even if

containing nonfatal errors
Z = abort task if fatal error(s) occurs, but continue

processing of job

no X, Y, and Z = task will be completed; errors inhibit compilation

#### COMMON SPECIFICATIONS

(where listed with statement):

Library specification: SYS = systems library

JOB = job library

xxxxx = group library number; 5-digit octal or 4-digit decimal (+D)

Name/Version: element name, (up to) 10 alphanumeric/element version,(up to)

5 alphanumeric characters

File Code: A through Y and AA...AZ,BA...BZ,...YA...YZ

File Name: (up to) 15 alphanumeric characters to identify tape reel

## SECONDARY CONTROL STATEMENT FORMAT

t	mnemonic	70	optionoptionoption	75	v <sub>0</sub> ,v <sub>1</sub> ,v <sub>2</sub> ,,v <sub>n</sub>	
t	operator	ъ	option(s)	ъ	specification(s)	

### SERVICE REQUEST FORMAT

↓ col	umn	18		
mnemonic	\$	ъ	v <sub>0</sub> ,v <sub>1</sub> ,v <sub>2</sub> ,,v <sub>n</sub>	
operator	\$	Т	specification(s)	

#### (A) I/O STATUS WORD (GENERAL)

i status code

29 28	24 23	18 17	0
i: abnorr	mal status condition ind	icator	
status co	de: 01 = inappropriate	function	
	02 = incorrect para	meter	
	03 = unrecoverable	subsystem error	
	04 = end-of-file		
	05 = end-of-tape		
	06 = unsuccessful	search	
	07 = illegal charac	ter	
	10 = no assignment		
	11 = interlock		
	12 = hidden file se	gment	

number of words transferred

